


User Manual for C1100M8-12GX (Self-Selection Type)



Before Operation:

Before issuing MF1 keys, please choose Free Key or Non-Free Key operating mode and Manual or Automatic locking mode first, that depends on 2 switches' position as below:

Assign-use Key Mode: S1 on left side (S) (under this mode, the guest key can be used for only 1 specified locker)

Free-use Key Mode: S1 on right side (D) (under this mode, the guest key can be used for any unoccupied locker)

Manual Locking Mode: S2 on left side(M)

Automatic Locking Mode: S2 on right side(A);

Set New Keys:

A. Set Owner Key (1 Owner key for 1 lock)

After loading the batteries into battery holder, touch the first MF1 key on the receptor, the key set as owner key.

Change Owner Key:

Press the "Reset" button and hold for 1 second, blue light will on, after 3 beeps sound, touch a MF1 key on the receptor, the key set as new owner key (all the existing keys will be deleted).

Note: Only one owner key is allowed for a lock, the owner key is used to issue or delete master key, but not used to unlock.

B. Set Master Key(1 Master Key for 1 lock)

Touch owner key on the receptor, after a "beep" sound, blue light slowly blink, touch a MF1 key, after a "beep" sound, blue light will off, and the key set as master key.

C. Set Service Keys

Touch master key on the receptor, after, blue light fast blink, touch the master key again, a "beep" sounded again, blue light fast blink again, touch a MF1 key, after a "beep" sound, the key is service key (before the light is off, some more service keys can be issued until

maximum 12 pcs).

Note: When issue/delete service key, the guest key will be deleted

D. Set Assigned-Use Guest Key (switch S1 on left side)

Touch master key to sensor, a "beep" sounded, blue light fast blink, touch a MF1 key, after a "beep" sound, blue light will off, the key has been set as assigned-use guest key.

Note: Only 1 guest key is allowed for each lock.

E. Set Free-Use Guest Key (switch S1 on right side)

Touch a Free MF1 key to Sensor, after two "beep" sounded, the cabinet lock will closed, this MF1 Key has been set as Free-use Guest key.

Note: 1. Only 1 guest key is allowed for each lock at the same time.

2. One guest key can occupy 1 locker only.

3. Guest key will be deleted if cabinet lock been opened by Master Key or Service Key.

4. Guest Key should be Renew by BT Init_B v1.0 software if cabinet locks been opened by Master Key or Service Key.

5. All MF1 keys need to initialize by Init_B v1.0 software at first time before use.

Delete Key(s)

A. Delete Master Key(s)

Touch owner key on the receptor, after a "beep" sound, blue light slowly blink, touch another new MF1 key, a "beep" sounded, blue light is off, the previous master key will be deleted, and new master key will be available.

Note: Only 1 master key is allowed for one lock, the master key is used to Issue or delete service key and guest key; and can be used to lock/unlock. When a new master key is issued, all the existing master key, service key and guest key will be deleted.

B. Delete Some Service Key

Touch master key on the receptor, a "beep" sounded, blue light fast blink, touch the master key again, a "beep" sounded again, blue light fast blink again, touch the service key which you want to delete, after 2 "beep", the service key will be deleted(before the blue light off, some more service keys can be deleted at the same way).

C. Delete All Service Keys

Touch master key on the receptor, a "beep" sounded, blue light fast blink, touch the master key again, a "beep" sounded again, blue light fast blink again, touch master key the third time, after 3 "beeps", all service keys will be deleted.

D. Delete Guest Keys

Guest key will be deleted if cabinet lock been opened by Master Key or Service Key.

NOTE:

Regarding Locking Mode:

Manual Locking Mode: Touch a workable Key, a "beep" sounded then open; touch Key again

two “beep” sounded then close.

Automatic Locking Mode: Touch a workable Key, a "beep" sounded then open; and automatic close in 4 seconds.

Note: 1. Manual Locking Mode will auto activate if Free-Use Key mode has been activated.

Emergency Power Back-up

In case the batteries runs out completely, please insert the 6V power backup-battery-case to the emergency socket or connect 9V battery to the electric-pole, then use workable key to unlock the lock.

Alarm Function

Low Battery Alarm: When the battery voltage drop to DC $4.2V \pm 0.2V$, the blue light blinks and 8 “beeps” are sounded after the locker opened by keys each time, the batteries need to replace.

Incorrect Key Alarm: Touch any incorrect key, 3 "beeps" are sounded; touch any incorrect key 3 times, blue light will on, and the alarm last for 60 seconds.

Anti-pick Alarm: In locking state, if latch be pressed, blue light will on, and alarm last for 60 seconds.

Improperly-locking Alarm :When the lock is locked improperly like the lock latch stopped by clothing or not close the door completely, after 3 seconds, blue light will on, the alarm last for 60 seconds to remind the user to check the locker and lock the door properly.

Occupied Indication: In Free-Use Key mode, when cabinet lock has been occupied by any Free-use guest Key, the blue light will blink 1 time every 2 seconds to indicate the users that this cabinet lock has been occupied.